


BANDAI ELECTRONICS

LSI Portable Game


TORPEDO SHOOT

INSTRUCTION

Please read carefully before playing.




PART NAMES




2 TO INSERT BATTERY

1. Slide and open battery cover as per arrow indicator.




2. Attach 9 volt battery as shown in diagram.



**DO NOT REVERSE
TERMINALS.**

3. Slide and close cover.



★After playing, take off battery.

3 FUNCTION



- Power Switch (ON-OFF)
Switch on to start game
Switch off after final score is registered.
Switch on to start game again.



- Firing Button
Firing button to shoot torpedo from your submarine.



- Action Button
Use these buttons to move your submarine.
Arrows indicate what direction submarine will move.

- Digital Counter
When your torpedo hits.
"Fast enemy boat," you will gain 5 points, and hits
"Slow enemy boat," 1 point will be given.


If your score more than 99 points - the following will appear.

POINT	DIGITAL COUNTER
100~109	00~09
110~119	10~19
120~129	20~29
130~139	30~39
140~149	40~49
150~	Come back to 0



Q HOW TO PLAY

OBJECT: SEE HOW MANY POINTS YOU CAN SCORE WITH 30 TORPEDOS.


1. Switch power "ON" - Your submarine and enemy boat appear. Enemy boat moves right or left with dropping depth charge.



2. Escape the attack of enemy boat by operating Actino button.



3. Press firing button, attack enemy boat.



4. You have 30 torpedos in your submarine. If your submarine is hit by enemy's depth charge you'll lose 5 torpedos at once.

Caution: In case your torpedo hits enemy's depth charge, your torpedo will disappear.

-
-
5. Depend on the speed of enemy boat, you'll gain 3 or 5 points.
 6. When you have shot 30 torpedos or spent 30 torpedos, game is over. (When your submarine is hit, you'll lose 5 torpedos.)
 7. To play again, switch "OFF" and then switch "ON" again.

● SOUND EFFECT

This game features 5 sorts of effective sound.

★Game progressing sound

★Firing sound

★Destruction sound

★Explosion sound

★Game over sound

5 IMPORTANT

Should screen image or scoring begin to malfunction, this is the first sign of battery wear.

A new battery will solve the problem.

Use 9 volt alkaline battery for long life.

www.handheldmuseum.com

Specification

Name: Bandai Hand Held
Torpedo Shoot

Battery: Requires one 9 volt (not included)

Large Scare Intergrated Aicuit Construction

90 DAY LIMITED WARRANTY

Bandai Electronics Arcade Games are manufactured under stringent quality control conditions. We warrant (to the original consumer purchaser) for a period of 90 days from the date of the purchase that our Electronics Arcade Games will be free of defects in materials and workmanship under normal use.

If, within the 90 day warranty period, you find your game to be not functioning properly, please consult your instruction manual for a possibly simple remedy to your problem. If such consultation does not remedy the malfunction, your game will either be repaired or replaced with a new model without charge to the retail establishment where purchased with proof of purchase date, or by sending with proof of purchase date to:

BANDAI ELECTRONICS REPAIR CENTER
6 Pearl Court
Allendale, NJ 07401

BANDAI ELECTRONICS WILL NOT BE LIABLE FOR DEFECTS CAUSED BY MISUSE OF PRODUCT. WE WILL ALSO NOT BE RESPONSIBLE FOR DAMAGES OR LOSS IN TRANSIT FROM CONSUMER TO OUR REPAIR CENTER.

To service your game, please do the following:

1. Pack the game carefully (in original box if possible) with adequate padding material.
2. Carefully print the following address on your outer carton:

BANDAI ELECTRONICS REPAIR CENTER
6 Pearl Court
Allendale, NJ 07401

With normal use and care your Bandai Electronics Arcade Game should provide you with many hours of enjoyment.



PRINTED IN JAPAN